



## **Bat-Caddy X4 Series Upper Circuit Board Replacement**

1. With a razor blade knife, peel back the top of the thin faceplate (with the on/off button on it) until you see a Philips screw.
2. Take the screw out and press the faceplate back down so the adhesive doesn't dry out.
3. Remove the black circuit board holder.
4. Carefully unplug the wire connectors from the back of the board.
5. Remove the two Philips screws from the holder and remove the circuit board.
6. Screw the replacement board in and plug in the wire connectors.
7. Put the circuit board holder back in place and screw it down.